



# INSTRUCTIONS FOR THE TEST KIT

# FESTFLOOR® LIFE

## THE KIT INCLUDES:

### 1 FESTGrunt

Acrylic product for priming surfaces, evens out absorption, improves adhesion.




### 2 FESTFLOOR BASE, A+B

Two-component primer for reinforcing substrates and bonding fibreglass mesh before the



### 3 Fibreglass mesh

For the reinforcement of the substrate for microcement and prevents the transmission of cracks from the concrete screed to the top of the microcement.



### 4a FESTPowder

A micro-mortar for the creation of highly durable decorative flooring. Should be mixed with FESTLiquid and FESTColor.



### 4b FESTLiquid 2 pcs

Liquid polymer - complementary product supplementary product for making more fluid consistency of the decorative compound.



### 4c FESTColor

Liquid pigment for the colouring of Festfloor® Life microcement.



### 5 PU FEST 2K component A and B

Polyurethane sealer for protection of the microcement



Scan the QR code, to access the technical data sheet of the product.



In addition to the Festfloor® Life kit, you also need: **a trowel, a microfibre roller, a sander and a Hoover.**

## MICROCEMENT APPLICATION INSTRUCTIONS:

### STEP I

Apply **FestGrunt 1** to the surface.

Then wait approximately 2h until dry.

If your substrate does not require reinforcement, skip STEP II and proceed to STEP III.

### STEP II

If your substrate requires reinforcement, use **Festfloor Base 2** and **fiberglass mesh 3**. Mix **Festfloor Base** component **A** with 2x **FESTLiquid** component **B** in a weight ratio of about 3:1 and apply. Next, paste the fiberglass mesh.

Wait 2h-4h until dry. Then sand the substrate with e.g. 60-grit paper and vacuum.

### STEP III

Mix the contents of two bottles of **FESTLiquid 4b** with the contents of a bucket of **FESTPowder 4a**. Finally add the measured **FESTColor 4c**. Apply the total to the previously prepared substrate.


Allow 2h-4h to dry. Then sand the substrate with a grade of paper e.g. 80 or higher, and then dust off.\*

### STEP IV

Sealer application:

Mix **PU FEST 2K** component **A 5** with **PU FEST 2K** component **B 5**, and then use a roller to spread it over the microcement surface, in order to protect it.

Wait 24 h until fully dry.\*\*



Scan the QR code for more information, including how to mix the colour properly. 



\*When making the target surface, the system provides for the application of two layers of microcement.

When making a sample from the test kit, you do not need to do this.

\*\* When making the target surface in some areas it is advisable to add a second coat of sealer (e.g. bathroom).

When making a sample from the test kit, you do not need to do this.