



## INSTRUCTIONS FOR THE TEST KIT

# HYDROFEST

### THE KIT INCLUDES:

#### 1 FESTGrunt

Acrylic product for priming surfaces, evens out absorption, improves adhesion.




#### 2 FESTKontakt

Quartz bonding bridge under plasters and levelling compounds, for smooth, non-absorbent wall and ceiling surfaces, concrete, OSB boards, tiles, etc.



#### 3 Fibreglass mesh

For the reinforcement of the substrate for microcement and prevents the transmission of cracks from the concrete screed to the top of the microcement.



#### 4 HYDROFEST

Ready-to-use, waterproof microcement for wet areas.



#### 5 PU FEST 2K component A and B

Polyurethane sealer for protection of the microcement



Scan the **QR code**, to access the technical data sheet of the product.

In addition to the HYDROFEST kit, you also need: **a trowel, a microfibre roller, a sander and a Hoover.**



# MICROCEMENT APPLICATION INSTRUCTIONS:

## STEP I

Apply **FestGrunt 1** to the surface.

Then wait approximately 2h until dry.

If your substrate does not require reinforcement, skip STEP II and proceed to STEP III.

## STEP II

If your substrate requires reinforcement, use **FestKontakt 2** and **fibreglass mesh 3**.

Wait 2h-4h until dry. Then sand the substrate with e.g. 60-grit paper and vacuum.

## STEP III

Apply a layer of **HYDROFEST 4** with a trowel to the previously prepared substrate.


Allow 2h-4h to dry. Then sand the substrate with a grade of paper e.g. 80 or higher, and then vacuum. \*

## STEP IV

Sealer application:

Mix **PU FEST 2K** component **A 5** with **PU FEST 2K** component **B 5**, and then use a roller to spread it over the microcement surface, in order to protect it.

Wait 24 h until fully dry. \*\*



Scan the QR code for more information about the HYDROFEST system. 



\*When making the target surface, the system provides for the application of two layers of microcement.  
When making a sample from the test kit, you do not need to do this.

\*\* When making the target surface in some areas it is advisable to add a second coat of sealer (e.g. bathroom).  
When making a sample from the test kit, you do not need to do this.



FESTFLOOR | [hello@festfloor.com](mailto:hello@festfloor.com) | +48 537 991 307 | [www.festfloor.com](http://www.festfloor.com)